

INVISIBLE PATTERNS TECHNICAL TIPS

TWO PIECE BUMPERS



All Invisible Patterns Two Piece Bumpers are designed to ease installation whilst offering effective coverage to most vulnerable areas.

Fitment of two piece bumpers is the reverse to full wrap bumpers as you start from the outside wheel well and work in towards the centre. However they have the same style of excess material for folding into air vents etc.

Use either the wheel well, or cut out such as repeater lamp or pdc unit to line up and then work towards centre.

When joining in the centre it is important to ensure that the two pieces align or else this will spoil the appearance of the installation.

Take caution not to overstretch the centre sections, but work along 3-4 inches at a time keeping straight until centre is reached.



Example 1.

